




Full Overlay



Half Overlay




Inset Application



1. Drill 35mm hole in door at required height and hinge cup centre point.
2. Screw on or insert hinge.
3. Mark centre height of hinge arm on side frame.
4. Position mounting plate 37mm from edge of side frame.

Hinge cup centerpoint



C = Cup centerpoint


20.5	21.5	22.5	23.5	24.5	25.5
13/16"	27/32"	7/8"	15/16"	31/32"	1"
3	4	5	6	7	8

B = Bore distance




B = Bore distance

Deactivation switch on hinge cup

For small or light doors, the BLUMOTION can be deactivated on one of the hinges.




Number of Hinges




INSERTA


Tool-free attachment with INSERTA expanding Ø8 mm dowels



FOR INSET APPLICATION ADD
THICKNESS OF DOOR TO THE
37MM MEASUREMENT
e.g. DOOR THICKNESS = 16mm
 $37 + 16 = 53\text{mm}$



Screw-on
Use #6 wood screws



The number of hinges depends on the front weight.

To achieve good stability, distances between hinges should be as large as possible.

Indications on weight and height apply to a standard door width of 600 mm.